

th•mann

DP-31 B, DP-31 WH
digital piano



Musikhaus Thomann
Thomann GmbH
Hans-Thomann-Straße 1
96138 Burgebrach
Germany
Telephone: +49 (0) 9546 9223-0
E-mail: info@thomann.de
Internet: www.thomann.de

Table of contents

1	General information	5
1.1	Further information	5
1.2	Notational conventions	5
1.3	Symbols and signal words	6
2	Safety instructions	7
3	Features	9
4	Assembly instructions	10
5	Control panel and connections	17
6	Connectivity options	20
7	Switching on / off and basic operation	22
7.1	Turning the digital piano on and off	22
7.1.1	Normal switching on / off	22
7.1.2	Automatic shutdown	22
7.2	Setting up the digital piano, Function menu	22
7.2.1	Transposing	23
7.2.2	Fine tuning	23
7.2.3	Beats	24
7.2.4	Touch sensitivity	24
7.2.5	Split point	24
7.2.6	DSP effects depth	25
7.2.7	Midi receive channel (Midi In)	25
7.2.8	MIDI send channel (Midi Out)	25
7.2.9	Automatic shutdown	25
7.3	Adjusting the volume	26
8	Operating	27
8.1	Demo songs	27
8.2	Practise songs	28
8.3	Dual mode	29
8.4	Split mode	29
8.5	Selecting voices	29
8.6	Style mode	30
8.6.1	Style selection	30
8.6.2	Starting a Style	31
8.6.3	Ending a Style	31
8.6.4	Accompaniment track volume	32
8.6.5	Accompaniment track tempo	32
8.7	Metronome	32
8.8	Auto Accompaniment	33
8.9	Fill A/B	33
8.10	Chord detection	34
8.11	Mixer	38

Table of contents

8.12	One Touch Setting.....	39
8.13	Recording function.....	39
8.13.1	Record stand-by.....	39
8.13.2	Start recording.....	40
8.13.3	Stopping recording.....	40
8.13.4	Playback recordings	40
8.14	Memory.....	41
8.14.1	Memory banks.....	41
8.14.2	Memory data.....	41
8.14.3	Load / save parameters.....	42
8.14.4	Deleting memory data.....	42
9	Voice list.....	43
10	Styles list.....	46
11	Practise and demo songs.....	48
12	Chord list.....	50
13	MIDI implementation chart.....	52
14	Technical specifications.....	54
15	Protecting the environment.....	55

1 General information

This manual contains important instructions for the safe operation of the unit. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the device. If you sell the unit please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.

1.1 Further information

On our website (www.thomann.de) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

1.2 Notational conventions

This manual uses the following notational conventions:

Letterings

The letterings for connectors and controls are marked by square brackets and italics.

Examples: [VOLUME] control, [Mono] button.

Displays

Texts and values displayed on the device are marked by quotation marks and italics.

Examples: '24ch', 'OFF'.

Instructions

The individual steps of an instruction are numbered consecutively. The result of a step is indented and highlighted by an arrow.

Example:

1. ➤ Switch on the device.
2. ➤ Press [Auto].
⇒ Automatic operation is started.
3. ➤ Switch off the device.

Cross-references

References to other locations in this manual are identified by an arrow and the specified page number. In the electronic version of the manual, you can click the cross-reference to jump to the specified location.

Example: See ↗ 'Cross-references' on page 6.

1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – high-voltage.
	Warning – danger zone.

2 Safety instructions

Intended use

This device is intended to be used for electronic sound generation using a piano keyboard. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Safety



DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.



DANGER!

Electric shock caused by short-circuit

Do not modify the mains cable or the plug. Failure to do so could result in electric shock/death or fire. If in doubt, seek advice from a registered electrician.



DANGER!

Electric shock caused by high voltages inside

Within the device there are areas where high voltages may be present. Never remove any covers.

There are no user-serviceable parts inside.



CAUTION!

Possible hearing damage

With loudspeakers or headphones connected, the device can produce volume levels that may cause temporary or permanent hearing impairment.

Do not operate the device permanently at a high volume level. Decrease the volume level immediately if you experience ringing in your ears or hearing impairment.

**CAUTION!****Risk of injury due to heavy weight**

Due to the heavy weight of the device, at least two persons are required for transport and installation.

**NOTICE!****Operating conditions**

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.

**NOTICE!****Power supply**

Before connecting the device, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly injure the user.


Unplug the device before electrical storms occur and when it is unused for long periods of time to reduce the risk of electric shock or fire.

3 Features

The digital piano is characterized by the following features:

- 88 weighted keys with hammer action, touch velocity in 3 steps.
- Multi function LCD.
- User-friendly controls and indicators.
- 220 voices. 16 voices available via direct selection buttons.
- 120 styles. 12 styles available via direct selection buttons.
- 60 practise songs.
- Three demo songs.
- Single and multi-finger chord detection.
- Recording function.
- Four memory banks, each with four memory locations.
- Mixer function.
- Connections: USB, 2 × headphones, audio outlet, pedal box.

4 Assembly instructions




You need a Phillips screwdriver (not supplied) for the assembly of the digital piano. Open the package and please make sure before assembling that the entire scope of delivery is present, as posted here.


1	Digital piano housing with music stand
2	Right side panel
3	Left side panel
4	Back panel
5	Pedal box
6	10 × screws 6 × 60
7	5 × screws 4 × 15
8	2 × screws 6 × 12
9	4 × hand screws
10	Power cord
11	Pedal cable
12	4 × plastic caps
13	2 × body feet

Mechanical assembly

1. ➤ Assemble the piano near a wall power outlet.
2. ➤ Proceed according to the illustrations and exclusively use the supplied screws. Using other screws could damage the piano housing or result in a reduced stability of the piano.




3. ➤ Screw the body feet to the side panels (6 x screws 6 x 60).




4. ➤ Screw the pedal box to the two side panels (4 x screws 6 x 60) and insert the four supplied plastic caps into the screw holes.


Assembly instructions



- 5.** Attach the back panel to the pedal box (5 × screws 4 × 15) and to the backs of the side panels (2 × screws 6 × 12).



- 6.** Put the digital piano housing on the stand and affix it using the four supplied hand screws.





- 7.** Fasten the cables to the stand. Insert the DIN plug of the pedal cable into the provided socket on the bottom side of the digital piano. Move the digital piano to its designated location.

Mains connection

1. ➤ Make sure that the piano is turned off before you connect the device to the power supply or disconnect it.

2. ➤ Turn the volume control to minimum.




3. ➤ Plug the power cord into a 230 V AC outlet.


4. ➤ Now you can turn on the device.



If the piano is not in use or when a thunderstorm with danger of lightning threatens, disconnect the device from its mains power for safety.


Assembly overview**Top view**

1	Operating panel
2	Headphone sockets
3	Music stand
4	Piano keyboard

**Rear panel**

5	Connection for pedal cable
6	Power cord
7	USB port
8	AUX stereo outlet

Assembly instructions




Pedals

9	Soft pedal
10	Sostenuto pedal
11	Sustain pedal

5 Control panel and connections


Operating panel



1	On / off switch
2	Volume control
3	Direct selection buttons for styles selection.
4	Button for operating mode STYLES <ul style="list-style-type: none"> [START / STOP] [SYNC] [INTRO / ENDING] [FILL A] [FILL B] [A.B.C.]
5	[ACC. VOL +]/[ACC. VOL -] Buttons for Auto Accompaniment volume control.
6	[TEMPO +]/[TEMPO -] Buttons to increase / decrease the playback tempo.
7	[MIXER] Button to adjust the volume of each track.
8	[FUNCTION] Button to call the function menu.

Control panel and connections


9	[METRO]
	Button to turn the metronome on or off.
10	Display.
11	[STYLE]
	Button to open Styles selection.
12	[VOICE]
	Button to open instrument voice selection.
	If you press the buttons [STYLE] + [VOICE] simultaneously you enable the DEMO mode.
13	[SONG]
	Button to open practise song selection.
14	Selection panel with jog dial and buttons [+/-] and [-/+].
15	Direct selection buttons for instrument voice selection.
16	[BANK]
	Button to select the memory bank.
17	[STORE]
	Store button.
18	Memory location buttons [M1] to [M4] for 'One Touch Setting'.
19	[O.T.S]
	Key to enable the One-Touch-Setting function.
20	[DUAL]
	Button to call the Dual mode (two voices simultaneously).
21	[SPLIT]
	Button to call the Split mode (two different voices in different keyboard areas).
22	[REC]
	Button to switch to recording mode.
23	[PLAY / STOP]
	Button to playback songs.

Display

1	A.B.C. (automatic chord detection and bass accompaniment)	9	VOICE / STYLE / SONG / DIR (directory) / FILE
2	FILL A (fill bar A)	10	CHORD
3	FILL B (fill bar B)	11	TEMPO
4	MELODY OFF (right hand muted)	12	MEASURE
5	DUAL (Dual mode)	13	BEAT
6	SPLIT (Split mode)	14	MEMORY / TICK (metronome) / O.T.S.
7	TOUCH (touch sensitivity)	15	DSP (digital effects)
8	RECORD		

6 Connectivity options

Headphones




On the left below the keyboard you find headphone jacks.

1. If you plug a stereo headphones (not supplied) into headphone socket 2, the speakers are muted so that you can hear the sound only from the headphones.
2. If you plug a stereo headphones (not supplied) into headphone socket 1, you will hear the sound from both speakers and headphones.



- *Never operate the headphones at high volume as this can permanently damage your hearing.*
- *To avoid damage to the speakers, make sure before connecting the power supply or a device to the digital piano that the volume is set to 'minimum'.*

AUX output




You can connect powered speakers, your stereo system or other amplifiers to the rear AUX output.




For stereo playback, connect both channels (L and R). For mono playback, connect only one channel.

USB connection



1. Connect a computer or other device with USB support.
2. This USB port is a built-in MIDI-USB adapter. For devices with USB cable, you can simply connect the MIDI / USB converter to the USB port and connect the MIDI IN or MIDI OUT cable to the digital piano. After the driver is installed and the installation is complete, you can select the USB audio device in the Device menu of the software to transfer MIDI data.

Pedals



1. Connect the foot pedal to the provided connector on the bottom of the pedal box.

2. Pedal functions:

Soft pedal

Using the Soft pedal makes the piano sound smoother and the overall volume is attenuated.

Sostenuto pedal

When stepping on the Sostenuto pedal, the currently played notes linger until you release the pedal.

Sustain pedal

With the sustain pedal all played notes sound longer. This effect simulates the lifting of the damper in an analogue keyboard instrument.

7 Switching on / off and basic operation

7.1 Turning the digital piano on and off

7.1.1 Normal switching on / off



Press the power button on the left of the operating panel to turn the device on and off.



If the display does not light up after switching on the digital piano, check the power supply.

If you hear nothing coming from the speakers, the volume may be set to 'minimum'.

7.1.2 Automatic shutdown

If the digital piano is not in use, it shuts off after 30 minutes automatically. For adjusting or disabling the automatic shutdown, please proceed as described here ↗ [Chapter 7.2.9 'Automatic shutdown' on page 25](#).

To turn the device on again after an automatic shutdown, press the on / off switch to the left of the panel.

7.2 Setting up the digital piano, Function menu

Press the button [FUNCTION] to call the Function menu. The first function to appear after activation is 'Transpos'. Press the button [FUNCTION] repeatedly to open the desired sub menu. You can then change the parameters using the jog dial or the buttons [+/-] or [:]:

Option	LCD	Control range	Default value
Transposing	Transpos	-12 ... +12	0
Fine tuning	Tune	-50 ... 50	0
Beat	Beat	0, 2 ... 9	4
Touch sensitivity	Touch	OFF, 1, 2, 3	2
Split point	Split pt	1 ... 88	34 (F3 [#])
Reverb level	DSLevel	OFF, 1 ... 7	2
MIDI receive channel	Midi In	01 ... 16, ALL	ALL


Option	LCD	Control range	Default value
MIDI send channel	Midi Out	01 ... 16	01
Automatic shutoff	Power off	030, 060, OFF	030



If you don't press any key within five seconds after entering the function menu, the menu is automatically closed.

7.2.1 Transposing

With this function you can adjust the pitch of the keyboard in 12 semitone steps up or down.




1. ➔ Use [FUNCTION] to switch to 'Transpos' menu. The current setting appears on the display.
2. ➔ Adjust the pitch using the buttons [+] or [-] or the jog dial.
3. ➔ Simultaneously press [+] and [-] to restore the default setting (no transposing).



If you do not press any button for five seconds after opening the TRANSPOSE menu, it will quit automatically.

7.2.2 Fine tuning

With this function you can fine tune the entire keyboard in cent steps.



1. ➔ Use [FUNCTION] to switch to 'Tune' menu. The current setting appears on the display.
2. ➔ Adjust the tuning using the buttons [+] or [-] or the jog dial in a range of -50 to +50 cents. Each time a key is pressed, the value changes by 1 cent.
3. ➔ Simultaneously press [+] and [-], to reset the tuning to the default value.

7.2.3 Beats

With this function you can set the beats in a range from 0 to 9.



1. Use [FUNCTION] to switch to 'Beat' menu. The current setting appears on the display.
2. Adjust the beat using the buttons [+] or [-] or the jog dial.

7.2.4 Touch sensitivity

With this function you can adjust the touch response of the keyboard at four levels.

Parameter	Description
'OFF'	Touch sensitivity is off. This can be very recommendable when playing the organ voice.
'1'	Soft In this setting, the volume is higher than usual even when playing with a soft touch.
'2'	Normal This setting corresponds to the usual touch response of a keyboard.
'3'	Hard In this setting, the volume is lower than usual even when playing with a hard touch.



1. Use [FUNCTION] to switch to 'Touch' menu. The current setting appears on the display.
2. Adjust the Touch sensitivity using the buttons [+] or [-] or the jog dial.
3. If choosing 'OFF', the 'Touch' display turns off and the function is disabled.

7.2.5 Split point

Use this function you can select a point to split the whole keyboard into two areas.



1. Use [FUNCTION] to switch to 'Split pt' menu. The current setting appears on the display.
2. Set the desired split point using the buttons [+] or [-] or the jog dial, or just press the piano key that you want to be the split point. The keys to the right of this point are the right hand area, the keys of the other sides are the left hand area (chord area).

7.2.6 DSP effects depth

This function lets you change the intensity of the various effects.



1. Use [FUNCTION] to switch to 'DSP Level' menu. The current setting appears on the display.
2. Adjust the Effects depth using the buttons [+] or [-] or the jog dial.

7.2.7 Midi receive channel (Midi In)

Here you can define on which channel the digital piano receives MIDI information from other devices.



1. Use [FUNCTION] to switch to 'Midi In' menu. The current setting appears on the display.
2. Set the desired MIDI receive channel using the buttons [+] or [-] or the jog dial.

7.2.8 MIDI send channel (Midi Out)


Here you can define on which channel the digital piano sends MIDI information to other devices.



1. Use [FUNCTION] to switch to 'Midi Out' menu. The current setting appears on the display.
2. Set the desired MIDI send channel using the buttons [+] or [-] or the jog dial.


7.2.9 Automatic shutdown

Here you can specify whether and after what time the automatic shutdown of the digital piano is carried out.



1. Use [FUNCTION] to switch to 'Power Off' menu. The current setting appears on the display.
2. Use [+] and [-] or the jog dial to select one of the following options:
 - '030' (automatic shutdown after 30 minutes)
 - '060' (automatic shutdown after 60 minutes)
 - 'OFF' (automatic shutdown off).
3. If you press the buttons [+] and [-] simultaneously, the default setting (automatic shutdown after 30 minutes) is re-activated.

7.3 Adjusting the volume





Use the rotary control [*VOLUME*] to set a comfortable volume for playing and practising. Turn this control clockwise to increase the volume. Turn it counter-clockwise to reduce the volume.

8 Operating

8.1 Demo songs


The digital piano offers a total of three demo songs (see *Chapter 11 'Practise and demo songs' on page 48*).

1. ➤ Simultaneously press [VOICE] and [STYLE] to play demo songs.
2. ➤ Use [+] or [-] or the jog dial to select the desired demo song.
3. ➤ Press again simultaneously [VOICE] and [STYLE] or [START / STOP] to stop playback.



8.2 Practise songs

The digital piano offers 60 practise songs, where you can mute the right hand voice and play this part yourself.



1. Playing and stopping practise songs

Use [SONG] to switch to Demo song mode. The 'SONG' display appears on the display.

If you press [SONG] again, all practise songs are played successively in an endless loop.

If you press [START / STOP] the currently shown practise song will be repeated in an endless loop.

Press the button [START / STOP] again to stop the currently playing practise song.

2. Selecting a practise song

Use the buttons [+] and [-] or the jog dial to select the desired practise song. The display shows the respective title.

3. Pre-count

One bar will be pre-counted before playback begins. The bar display starts with a negative value. The practise song starts with bar 1.

4. Muting the melody track


Press the button [MELODY OFF] to mute the right hand voice. 'MELODY OFF' lights up in the display and you only hear the left hand voice. Press the button [MELODY OFF] again to re-enable the track.

5. Leaving the practise mode

To exit the practise song mode press one of the [STYLE], [VOICE], [DUAL] or [LOWER] buttons.

8.3 Dual mode

In Dual mode, you can play two voices simultaneously. 'VOICE R1' is displayed when the DUAL function is turned off. 'VOICE R2' is displayed when the DUAL function is turned on.




1. Use [DUAL] to switch to Dual mode.
⇒ The corresponding icon on the display indicates that the mode is active.
2. Use the buttons [+] or [-] or the jog dial to select the desired Dual voice. The default preset voice in Dual mode is no. '050 Strings2'.
3. Press again [DUAL] to exit Dual mode. Dual voice 'VOICE R2' will be disabled and you will only hear the (first) voice set for 'VOICE R1'.



When the keyboard is split, the Dual mode affects only the keys to the right of the keyboard split point. In the area to the left of the split point, chords are supposed to be played.

8.4 Split mode

With this function, you can assign different voices to certain keyboard areas.





1. Use [SPLIT] to switch to Split mode and to enable the left hand voice.
⇒ The corresponding icon on the display indicates that the mode is active. 'VOICE L' appears at the same time on the display.
2. Use the buttons [+] or [-] or the jog dial to select the desired Dual voice. The default preset left hand voice in Split mode is no. '049 Strings1'.
3. Press again [SPLIT] to exit Split mode. The 'SPLIT' display turns off on the display.

8.5 Selecting voices

The digital piano offers 220 voices in total (see [Chapter 9 'Voice list' on page 43](#)).

16 voices can be called via direct selection buttons. Two voices are assigned to each direct selection button. With the first keystroke you activate the voice that is specified above the button, with the second keystroke you activate the voice that is specified below the button.




- When you turn on, the display 'VOICE R1' lights on the display and the name of the first voice is displayed.
- Use the direct selection buttons, the [+] or [-] or the jog dial to select the desired voice.

8.6 Style mode

The digital piano offers a total of 120 Styles (see [Chapter 10 'Styles list' on page 46](#)). By default, Style '001' is set.

8.6.1 Style selection




- Use [STYLE] to switch to Style mode.
 ⇒ The corresponding icon on the display indicates that the mode is active. At the same time the name of the last selected style will appear on the display.
- Press the buttons [+] or [-] or use the jog dial to select a style.
- Style selection via direct selection buttons**

You can also select the desired style using the direct selection buttons. Two styles are assigned to each direct selection button, one specified above the button and one below.

If you press the same button twice, the style changes from the upper one to the lower one or vice versa.

If you press another direct selection button, the new style is selected according to whether the previous style name was specified above or below the button.

8.6.2 Starting a Style



1. Instant start

With [START / STOP] you can start the active Style (drums only) immediately.

2. Chord mode (A.B.C.)

Use [A.B.C. / MELODY OFF] to switch to Chord mode. The A.B.C. icon appears on the display. The area to the left of the split point is now regarded as the chord area. If you play a chord with one or more fingers, bass and chord sound simultaneously.

Play chords in single or multi finger mode, see 'Chord detection' & 'Single and multi-finger mode.' on page 35.

3. SYNC START

Use [SYNC] to switch to Sync start mode.

⇒ Indicators 'BEAT 1' to 'BEAT 4' are flashing in the current tempo on the display. When you play the digital piano in this mode, the style will start automatically.



- When the Chord mode is off, press any key on the keyboard. Then, only the percussion rhythm is played.
- If the Chord mode is activated, press any key of the chord area to start the style with automatic bass and chord accompaniment.


4. INTRO / ENDING

Press [INTRO / ENDING] to insert an intro part before the style is playing.

Press [START / STOP] to play intro and main part.

Press [INTRO / ENDING] while the Style is playing to insert an ending part after the current Style.

8.6.3 Ending a Style



1. Instant ending

With [START / STOP] you can end the Auto Accompaniment at any time.


2. Ending

With [INTRO/ENDING] you can complete the song with an ending. The style stops after the ending.

3. SYNC


With [SYNC] you stop the Style. The Sync start mode is being activated.

8.6.4 Accompaniment track volume



1. You can adjust the style volume via the volume of the Auto Accompaniment.
2. Press [ACC. VOL +] or [ACC. VOL -] to set the volume.
3. Press [ACC. VOL +] and [ACC. VOL -] simultaneously to mute the accompaniment track.

8.6.5 Accompaniment track tempo




1. Press [TEMPO +] or [TEMPO -]. The set value flashes for about 2 seconds on the display.
2. During this time, you can set the tempo with the jog dial in a range of 30 ... 280.
3. Keep [TEMPO +] or [TEMPO -] pressed to cycle through the values.
4. Simultaneously press [TEMPO +] and [TEMPO -] to reset the tempo to the preset default value.



If you change the style during style playback the current tempo is adopted for the new style.

8.7 Metronome



1. Press [METRO] to enable the metronome. You can select beat and tempo in the function menu.
2. Press the button [METRO] again to disable the metronome.



If the Style mode is disabled, the beat set in the function menu is applied after turning on the metronome. If the Style mode is enabled, the beat of the current style is applied.

The metronome can be activated along with the style. If the style plays first, the metronome will be enabled with the next bar. On the other hand, the metronome responds instantly to the first beat of the style.

8.8 Auto Accompaniment

The accompaniment function is controlled via five parameters: INTRO, NORMAL, VARIATION, FILL (A-A, A-B, B-A, B-B) and ENDING.

1. ➤ INTRO

Press the button **[INTRO / ENDING]** before you start to play to insert an intro. Depending on the selected Style the rhythm starts with two to four bars, followed by the main part.

2. ➤ NORMAL and VARIATION

There are two kinds of main part, normal and variation, which consist of two to four bars, depending on the style.

3. ➤ FILL


With activated accompaniment, you can press the button **[FILL A]** or **[FILL B]** to insert a rhythm and accompaniment part.

4. ➤ ENDING

If you press the button **[INTRO / ENDING]** while Auto Accompaniment is activated, an ending part matched to the accompaniment is inserted and the performance ends.

8.9 Fill A/B

With this function you can insert fill bars.



- Keep the button **[FILL A]** or **[FILL B]** pressed while a Style is being played, the selected fill pattern is played until you release the key again.
- Press the button **[FILL A]**, when the Style playback has ended. Then the change to the NORMAL part takes place and 'FILL A' lights in the display.
- Press the button **[FILL B]**, when the Style playback has ended. Then the change to the VARIATION part takes place and 'FILL B' lights in the display.

8.10 Chord detection

By default, the 'Auto Bass Chord' (A.B.C.) is disabled. Press [A.B.C. / MELODY OFF] to enable the function. The area to the left of the split point is already known as the chord area. When you now play a chord, both bass and chord voices will sound together.



As the A.B.C. chord detection is based on the root note of the chord, some chords that could be played according to the chord dictionary can not be detected by A.B.C., such as B6, B_b6, B_b6(9), B6(9), Baug, B_baug, B_bm6, Bm6, Adim7, B_bdim7, Bdim.

Single and multi-finger mode.

If the chord is played on base of the illustration for multi-finger chords below, it will be detected as a 'multi-fingered' chord. If not, it will be detected as a 'single-finger' chord.

- Single finger chords

With this method, you can play chords with only one, two or three fingers within the capabilities of the auto accompaniment. Here we show you some examples of single finger chords (C, Cm, C7 and Cm7).

 C	• To play a major chord Press the root note of the chord
 Cm	• To play a minor chord Press the root note together with the nearest black key to the left of it .
 C7	• To play a seventh chord Press the root note together with the nearest white key to the left of it .
 Cm7	• To play a minor seventh chord Press the root notes together with the nearest white and black keys to the left of it (three keys altogether) .




When the A.B.C. function is activated, single-finger chords are detected when playing keys to the left of the split point.

- Multi-finger chords

With this method, you can play chords with normal fingering within the capabilities of the auto accompaniment. Here we show you 32 chords using the example of C chords.

0 C	1 C ₆	2 CM ₇	3 CM ₇ (#11)	4 CM(9)	5 CM ₇ (9)
6 C ₆ (9)	7 Caug	8 Cm	9 Cm ₆	10 Cm ₇	11 Cm ₇ (b5)
12 Cm(9)	13 Cm ₇ (9)	14 Cm ₇ (11)	15 CmM ₇	16 CmM ₇ (9)	17 Cdim
18 Cdim ₇	19 C ₇	20 C _{7sus4}	21 C ₇ (b5)	22 C ₇ (9)	23 C ₇ (#11)
24 C ₇ (b13)	25 C ₇ (b9)	26 C ₇ (13)	27 C ₇ (#9)	28 CM ₇ aug	29 C ₇ aug
30 Csus ₄	31 C1+2+5	The notes in brackets are optional; the chords will also be recognised without them.			



Major third – four half steps (semitones)



Minor third – three half steps (semitones)



Chord basics


A chord consists of three or more notes played together. The most commonly used chord is the triad consisting of three notes: Root, third and fifth of the corresponding scale. The C major chord for example is formed from the notes C (root), E (the third note of the C major scale), and G (the fifth note of the C major scale). In the C major chord shown, the lowest note is the root (this is the basic form of the chord – if you play other notes of the chord as the lowest note, this is called ‘chord inversion’). The root is the central sound of the chord on which the other chord notes are built upon. The interval between adjacent notes and the root determines whether the result is a major or minor third.

Chord structure

The lower interval in our triad (between root and third) determines whether the result is a major or minor triad. In addition, we can shift the highest note by a half step up or down to produce two additional chords.

The basic characteristic of the triad remains even if we change the order of the notes to create different inversions. Consecutive chords can be softly connected in a chord progression, e.g. by choosing suitable chord inversions (also called ‘voicings’).

Cm
Root note Chord type



■ Chord names


Chord names will tell you everything you need to know about a chord. Through the chord name you know the root, whether it is a major, minor, or diminished chord, whether a large or flattened seventh is needed and what changes or tensions are used – all at a glance.

■ Some chord types

Suspended 4th Perfect 5 th Perfect 4 th	7th Flattened 7 th Major chord	Minor 7th Flattened 7 th Minor chord	Major 7th Major 7 th Major chord
Minor/major 7th Major 7 th Minor chord	7th, flattened 5th Flattened 5 th 7 th chord	Minor 7th, flattened 5th Flattened 5 th Minor 7 th chord	7th, suspended 4th Flattened 7 th Suspended 4 th chord

8.11 Mixer

This menu is used to adjust the volume of the various style elements and instrument voices.



1. Press [MIXER] to open the Mixer menu. By default, the option 'Drum Vol' appears.
2. Repeatedly press the button [MIXER] to select the desired option (see chart).
3. Use the buttons [+] or [-] or the jog dial to select the desired value.



If you don't press any button within five seconds after calling the menu, the menu is automatically closed.

Adjustable options and parameters

Option	LCD	Control range	Standard	Description
DRUM volume	Drum Vol	000 ... 031	020	Drums accompaniment
BASS volume	Bass Vol	000 ... 031	018	Bass accompaniment
ORCHESTRA volume	Oc Vol	000 ... 031	021	Orchestra accompaniment
UPPER1 volume	Voice R1	000 ... 031	024	Right hand voice
UPPER2 volume	Voice R2	000 ... 031	012	Second right hand voice in Dual mode
LOWER volume	Voice L	000 ... 031	012	Left hand voice


8.12 One Touch Setting

One Touch Setting (O.T.S. or one-key operation) is a convenient function that allows you to immediately reconfigure all settings with just one single key press. This is about rhythm-based compilations of instrument voices. With this function, four parameter types (M1 to M4) can be loaded.

The default parameters stored in O.T.S. are:

- Right hand voice R1
- Second right hand voice in Dual mode R2
- Left hand voice L
- R1 volume
- R2 volume
- Orchestra accompaniment for R1
- Orchestra accompaniment for R2

1. Select a Style.
2. Use [O.T.S.] to switch to O.T.S. mode.
⇒ The display shows 'O.T.S.'
3. Press one of the buttons [M1] ... [M4].
⇒ The device loads the parameter types that match the current Style. The ABC mode is automatically turned on at that.
4. Press one of the buttons [M1] ... [M4] that provides your desired settings.
5. Press again [O.T.S.] to exit O.T.S. mode.
⇒ The display shows 'MEMORY'.




8.13 Recording function

8.13.1 Record stand-by



1. Use [REC] to switch to recording mode.
⇒ The corresponding icon on the display indicates that the mode is active. The indicators 'BEAT 1' ... 'BEAT 4' are flashing synchronously and thus indicate stand-by for recording.
2. Select the instrument voice and the Style and set the tempo and mixer parameters.


8.13.2 Start recording



1. Press [START / STOP] on the record enabled digital piano to start recording.



2. The indicators 'BEAT 1' ... 'BEAT 4' are flashing in the current tempo.



- When you turn off the digital piano the recording is maintained.
- If you keep the buttons [REC] and [PLAY / STOP] simultaneously pressed when turning the digital piano on, the stored recordings will be erased.
- If you keep the buttons [+] and [-] pressed when turning the digital piano on, the factory default settings are loaded and all stored recordings will be erased.

8.13.3 Stopping recording



- Press [REC] to stop recording.



When the memory is full the recording stops automatically. Then the display shows 'Full'.

8.13.4 Playback recordings



1. Press [PLAY / STOP] to play a recording.
2. Press again [PLAY / STOP] to stop playback.



If you press [PLAY / STOP] although there's no recording stored, the display briefly shows 'Empty'.


8.14 Memory

You can store 16 control panel configurations in the memory of the digital piano and recall the data any time, if required.

8.14.1 Memory banks

There are four memory banks in total. Each memory bank offers four storage locations (M1 to M4).

1. ➡ Press repeatedly [BANK] to select one of the four memory banks. The display shows 'MEMORY 0X'.
2. ➡ Press one of the buttons [M1] ... [M4] to select one of the four memory banks. The display shows 'MEMORY 0X-X'.



8.14.2 Memory data


The settings for the following functions can be stored as data in memory:

- Right hand voice R1
- Second right hand voice R2
- Left hand voice L
- Style
- Tempo
- Function
- Mixer
- Accompaniment volume.



If the current memory data are changed the corresponding memory display turns off.

8.14.3 Load / save parameters



1. Select the desired memory bank (see [Chapter 8.14.1 'Memory banks'](#) on page 41).

2. Storing a configuration

Keep the button [STORE] pressed and simultaneously press one of the buttons [M1] ... [M4]. The data are then stored in the respective memory location (M1 ... M4). Please note that any data previously stored there will be deleted.


3. Loading a configuration

Use the buttons [M1] ... [M4] to select the memory from which you want to load data. The data are instantly loaded and thereby replace the current settings. The SONG display appears on the display.



When you turn off the digital piano the stored data are retained.

8.14.4 Deleting memory data



1. If you keep the buttons [STORE] and [M1] pressed when turning the digital piano on again, the data from the memory are applied as standard values.
2. If you keep the buttons [+] and [-] pressed when turning the digital piano on, the factory default settings will be loaded and all stored recordings deleted.

9 Voice list

No.	Voice	No.	Voice	No.	Voice
001	Acoustic Grand Piano	031	Distortion Guitar	061	French Horn
002	Bright Acoustic Piano	032	Guitar Harmonics	062	Brass Section
003	Electric Grand Piano	033	Acoustic Bass	063	Synth Brass 1
004	Honky-Tonk Piano	034	Finger Bass	064	Synth Brass 2
005	Electric Piano 1	035	Pick Bass	065	Soprano Sax
006	Electric Piano 2	036	Fretless Bass	066	Alto Sax
007	Harpsichord	037	Slap Bass 1	067	Tenor Sax
008	Clavi	038	Slap Bass 2	068	Baritone Sax
009	Celesta	039	Synth Bass 1	069	Oboe
010	Glockenspiel	040	Synth Bass 2	070	English Horn
011	Music Box	041	Violin	071	Bassoon
012	Vibraphone	042	Viola	072	Clarinet
013	Marimba	043	Cello	073	Piccolo
014	Xylophone	044	Contrabass	074	Flute
015	Tubular Bells	045	Tremolo Strings	075	Recorder
016	Dulcimer	046	Pizzicato Strings	076	Pan Flute
017	Drawbar Organ	047	Orchestral Harp	077	Blown Bottle
018	Jazz Organ	048	Timpani	078	Shakuhachi
019	Rock Organ	049	Strings Ensemble 1	079	Whistle
020	Church Organ	050	Strings Ensemble 2	080	Ocarina
021	Reed Organ	051	Synth Strings 1	081	Square
022	Accordion	052	Synth Strings 2	082	Sawtooth
023	Harmonica	053	Choir Aahs	083	Calliope
024	Tango Accordion	054	Voice Oohs	084	Chiff
025	Nylon Guitar	055	Synth Voice	085	Charang
026	Steel Guitar	056	Orchestra Hit	086	Voice
027	Jazz Guitar	057	Trumpet	087	Fifths
028	Clean Guitar	058	Trombone	088	Bass Lead
029	Muted Guitar	059	Tuba	089	Fantasia
030	Overdriven Guitar	060	Muted Trumpet	090	Warm

Voice list

No.	Voice	No.	Voice	No.	Voice
091	Poly Synth	122	Breath Noise		ACCORDION
092	Choir	123	Seashore	151	Accordion 2
093	Bowed	124	Bird Tweet	152	Soft Accordion
094	Metallic	125	Telephone Ring	153	Soft Accordion 2
095	Halo	126	Helicopter	154	Harmonic
096	Sweep	127	Applause		GT & BASS
097	Fx1 (rain)	128	Gunshot	155	N-Gthamm
098	Fx2 (soundtrack)		KEYBOARD	156	PickGt
099	Fx3 (crystal)	129	Pianostr	157	PickGt2
100	Fx4 (atmosphere)	130	Modern Electric Piano	158	12Str Guitar
101	Fx5 (brightness)	131	Solo Piano1	159	Clean Guitar 2
102	Fx6 (goblins)	132	Polar	160	Clean Guitar 3
103	Fx7 (echoes)	133	Grand Harpsi	161	Clean Guitar 4
104	Fx8 (sci-fi)	134	Clavi 2	162	Solidwa
105	Sitar	135	Clavi 3	163	Overdriven Guitar 2
106	Banjo	136	Clavi 4	164	Overdriven Guitar 3
107	Shamisen	137	Bell	165	Tremolo Guitar
108	Koto	138	Bell 2	166	Funk Guitar
109	Kalimba	139	Vibes 2	167	Bass Cymbal
110	Bag Pipe	140	Vibesma	168	Synth Bass 3
111	Fiddle	141	Marimba 2	169	Synth Bass 4
112	Shanai		ORGAN		STRINGS
113	Tinkle Bell	142	Electric Organ	170	Viola 2
114	Agogo	143	Jazz Organ 2	171	Cello 2
115	Steel Drums	144	Jazz Organ 3	172	Cello 3
116	Wood Block	145	Clik Organ	173	Cello 4
117	Taiko Drum	146	Pop Organ	174	Strings Ensemble 3
118	Melodic Tom	147	Church Organ 2	175	Strings Ensemble 4
119	Synth Drum	148	Electric Organ 2	176	Synth Strings 3
120	Reverse Cymbal	149	Tremolo Organ	177	Dream Strings
121	Guitar Fret Noise	150	Q-Organ		

No.	Voice	No.	Voice	No.	Voice	
BRASS & PIPE						
178	Trombone 2	192	Softpad	208	BANG DI	
179	Trombone 3	193	Bellpad	209	XIAO	
180	FM Horn	194	Synpad	DRUM KIT		
181	Bbbrass	195	Hornpad	210	Standard Drum 1	
182	Hibrass	196	Newagpad	211	Standard Drum 2	
183	Tenosax 2	197	Bagpipe	212	Room Drum	
184	SoftSax	CHINES. INSTRUMENTE			213	Rock Drum
185	Basso 2	198	Pi PA	214	Electric Drum	
LEAD						
186	Whistle 2	199	YUE QIN	215	Analog Drumset	
187	Pan Flute 2	200	MID RUAN	216	Dance Drumset	
188	Lead1	201	GU ZHEN	217	Jazz Drum	
189	Lead3	202	YANG QIN	218	Brush Drumset	
190	Warplead	203	ER HU	219	Standard Drumset	
PAD						
191	Sinepad	204	GAO HU	220	Chinese Percussion	
		205	SUO NA			
		206	LU SHEN			
		207	QU DI			

10 Styles list

No.	Style	No.	Style	No.	Style
	8 BEAT & 16 BEAT				
001	8 Beat	028	Easy Ballad	055	Samba Funk
002	Guitar Pop 1	029	Love Ballad	056	Soul
003	8 Beat Disco	030	Natural Ballad	057	Soul Beat
004	8 Beat Dance	031	Piano Ballad	058	Hip Hop Soul
005	60s 8 Beat	032	EP Ballad	059	British Soul Pop
006	Pop Funk	033	New R&B Ballad	060	Hip Hop Beat
007	16 Beat Ballad		ROCK	061	R & B Ballad
008	Pop 16 Beat 1	034	Rock		JAZZ
009	Pop 16 Beat 2	035	Folk Rock	062	Swing
010	16 Beat Modern	036	Slow Rock 1	063	Jazz Brush
011	Modern 16 Beat	037	Hard Rock	064	Cool Jazz Ballad
012	16 Beat Bossa Nova	038	6/8 Rock	065	Acid Jazz 1
013	16 Beat Funk	039	Rock & Roll	066	Acid Jazz 2
014	Cool Beat	040	70's Rock & Roll	067	Big Band Medium
	POP	041	Rock Shuffle	068	Big Band Ballad
015	Guitar Pop 2	042	4/4 Blues	069	Swing Shuffle
016	Pop beat		DANCE	070	Fusion
017	Soft beat	043	Club Dance	071	Jazz Fusion
018	Sting Latin	044	Disco		COUNTRY
019	Brit Pop 1	045	70's Disco Funk	072	Country 8 Beat
020	Brit Pop 2	046	Garage	073	Country Pop 1
021	New Age	047	Rap 1	074	Country Ballad
022	Pop Hit	048	Rap 2	075	Modern Country
023	Fusion Shuffle	049	House	076	Country Folk
	BALLAD	050	Euro Dance	077	2/4 Country
024	Folk Ballad	051	Techno	078	Country Pop 2
025	Pop Ballad 1		SOUL & FUNK	079	Country Shuffle
026	Pop Ballad 2	052	Jazz Funk	080	Country Quick Steps
027	Rock Ballad	053	Cool Funky	081	Bluegrass
		054	Groove		

No.	Style	No.	Style	No.	Style
LATIN/BALLROOM					
082	Bossa Nova 1	096	March	108	Slow Rock 2
083	Rhumba	097	German March	109	Bossa Nova 2
084	Cha Cha Cha	098	6/8 March	110	Twist
085	Pop Cha Cha	099	Polka	INDONESIA	
086	Beguine	100	Polka Pop 1	111	Dandut 1
087	Tango	101	Polka Pop 2	112	Dandut 2
088	Swing Fox	102	Slow Waltz	113	Dangdu
089	Mambo	103	Country Waltz	114	Dangdut 1
090	Salsa	104	Jazz Waltz	115	Dangdut 2
091	Samba	105	Musette	116	Dangdut 3
092	Pasodoble	PIANO		117	Kercong 1
093	Slow Bolero	106	Pianist	118	Kercong 2
094	Habanera	107	Ballad	119	PopKcong
095	Latin Rock			120	Sdangdut

11 Practise and demo songs

No.	Title	No.	Title
PIANO			
001	Für Elise	027	Edelweiss
002	Habanera	028	O Sole Mio
003	Four Little Swans	029	Silent Night
004	Moseta Dance	030	Ave Maria
005	Germanic Dance	031	Five Hundred Miles
006	Turkish March	032	Happy New Year
007	March	033	It's Beginning To Look A Lot Like Christmas
008	Away In A Manger	034	Jeanie With The Light Brown Hair
009	Chopsticks	035	My Bonnie
010	2-Part Invention # 13 In A Minor.B.W. lli	036	Song Of The Pearlfisher
FOLK & COUNTRY			
011	Country	037	The Stage Coach
012	Jambalaya	038	Entertainer
013	Susanna	039	Annie Laurie
014	Bridge	040	Killing Me Softly With His Song
015	Battle Hymn Of The Republic	041	Last Rose Of Summer
016	The Old Gray Mare	042	The Old King Cole
017	American Patrol	JAZZ & FUSION	
018	In The Rain	043	Maple Leaf Rag
019	Sippin' Cider Through A Straw	044	June Samba
GOLDEN & POP			
020	Are You Lonesome Tonight	045	Funk
021	Only You	046	I Can....
022	End Of The World	047	Sea Shore
023	House Of Rising Sun	048	Guitar & Saxophone
024	The Blues-Bells Of Scotland	049	The Hip Hop's Night
025	Over The Rainbow	050	Blue Lunch
026	Beautiful Dreamer	051	Cobweb
		052	Wine
		053	Jazz Old Man
		054	Dark Eyes

No.	Title	No.	Title
055	Carlos		CHINESE
056	Sad	058	South Mud Bay
057	The Jazz	059	Give You A Rose
		060	Flowing Rill

Demo songs

No.	Name
001	DEMO 1
002	DEMO 2
003	DEMO 3

12 Chord list

	Chord description	Normal chord construction	Chord symbol	Display
0	Major [M]	1–3–5	C	C
1	Major sixth [6]	1–(3)–5–6	C6	C6
2	Major seventh [M7]	1–3–(5)–7	CM7	CM7
3	Major seventh with augmented eleventh [M7#11]	1–(2)–3–#4–(5)–7	CM7#11	CM7(#11)
4	Major add ninth [Madd9]	1–2–3–5	CMadd9	CM(9)
5	Major ninth [M9]	1–2–3–(5)–7	CM9	CM7(9)
6	Major sixth and ninth [6 9]	1–2–3–(5)–6	C6 9	C6(9)
7	Augmented [aug]	1–3–#5	Caug	Caug
8	Minor [m]	1–b3–5	Cm	Cm
9	Minor sixth [m6]	1–b3–5–6	Cm6	Cm6
10	Minor seventh [m7]	1–b3–(5)–b7	Cm7	Cm7
11	Minor seventh flattened fifth [m7b5]	1–b3–b5–b7	Cm7b5	Cm7(b5)
12	Minor add ninth [madd9]	1–2–b3–5	CMadd9	CM(9)
13	Minor ninth [m9]	1–2–b3–(5)–b7	Cm9	Cm7(9)
14	Minor eleventh [m11]	1–(2)–b3–4–5–(b7)	Cm11	Cm7(11)
15	Minor major ninth [mM7]	1–b3–(5)–7	CmM7	CmM7
16	Minor major ninth [mM9]	1–2–b3–(5)–7	CmM9	CmM7(9)
17	Diminished [dim]	1–b3–b5	Cdim	Cdim
18	Diminished seventh [dim7]	1–b3–b5–6	Cdim7	Cdim7
19	Seventh [7]	1–3–(5)–b7	C7	C7
20	Seventh suspended [7sus4]	1–4–5–b7	C7sus4	C7sus4
21	Seventh flattened fifth [7b5]	1–3–b5–b7	C7b5	C7(b5)
22	Seventh ninth [79]	1–2–3–(5)–b7	C7 9	C7(9)
23	Seventh sharp eleventh [7#11]	1–2–3–#4–(5)–b7 or 1–(2)–3–#4–5–b7	C7#11	C7(#11)
24	Seventh thirteenth [7 13]	1–3–(5)–6–b7 or 2–3–5–6–b7	C7 13	C7(13)
25	Seventh flattened ninth [7b9]	1–b2–3–(5)–b7	C7b9	C7(b9)
26	Seventh flattened thirteenth [7b13]	1–3–5–b6–b7	C7b13	C7(b13)
27	Seventh sharp ninth [7#9]	(1)–#2–3–(5)–b7	C7#9	C7(#9)
28	Major seventh augmented [M7aug]	1–3–#5–7	CM7aug	CM7aug
29	Seventh augmented [7aug]	(1)–3–#5–b7	C7aug	C7aug

	Chord description	Normal chord construction	Chord symbol	Display
30	Suspended fourth [sus4]	1–4–5	Csus4	Csus4
31	Suspended second [1+2+5]	1–2–5	C1+2+5	C

13 MIDI implementation chart

Function		Sent	Received	Notes
Basic Channel	Default	1	1 – 16	
	Changed	1 – 16	1 – 16	
Mode	Default	No	Mode 3	
	Messages	No	No	
	Altered	*****	No	
Note Number		9 – 120	0 – 127	
	True voice	*****	0 – 127	
Velocity Note	Note ON	Yes, 9nH, v = 1 – 127	Yes, 9nH, v = 1 – 127	
	Note OFF	No, 9nH, v = 0	No, 9nH, v = 0	
After Touch	Keys	No	No	
	Channels	No	No	
Pitch Bend		Yes	Yes	
Control Change	0	Yes	Yes	Bank Select
	1	Yes	Yes	Modulation
	5	No	Yes	Portamento Time
	6	Yes	Yes	Data Entry
	7	Yes	Yes	Volume
	10	No	Yes	Pan
	11	No	Yes	Expression
	64	Yes	Yes	Sustain Pedal
	65	No	Yes	Portamento ON/OFF
	66	No	Yes	Sostenuto Pedal
	67	Yes	Yes	Soft Pedal
	80	Yes	Yes	Reverb Program
	81	Yes	Yes	Chorus Program
	91	Yes	Yes	Reverb Level
	93	Yes	Yes	Chorus Level
	120	No	Yes	All Sound Off
	121	No	Yes	Reset All Controllers
	123	Yes	Yes	All Notes Off

Function		Sent	Received	Notes
Program Change	True #	Yes *****	Yes 0 – 127	
System Exclusive		No	Yes	
System	Song Position	No	No	
	Song Select	No	No	
	Tune Request	No	No	
System Real Time	Clock	No	No	
	Commands	No	No	
Aux Messages	Local ON/OFF	No	No	
	ALL Notes OFF	Yes	Yes	
	Active Sensing	No	Yes	
	Reset	No	Yes	
Notes:	<p>*1</p> <p>When the accompaniment starts, an FAH message is transmitted.</p> <p>When the accompaniment stops, an FCH message is transmitted.</p> <p>When an FAH message is received, the accompaniment starts.</p> <p>When an FCH message is received, the accompaniment stops.</p>			

MIDI channel modes

	POLY	MONO ON
OMNI ON	Mode 1	Mode 2
OMNI OFF	Mode 3	Mode 4

14 Technical specifications

Keyboard	88 weighted keys with hammer action and adjustable touch response	
Instrument voices	220	
Styles	120	
Demo and practice songs	3 demo and 60 practice songs	
Polyphony	64-voice (without DSP effects), 38-voice (with DSP effects)	
Display	Multifunctional LCD with blue backlight	
Switches and buttons	<p>[POWER], [VOLUME], [AUTO BASS CHORD], [MELODY OFF], [ACC. VOL +/-], [TEMPO +/-], [FUNCTION], [MIXER], [METRONOME], [DEMO], [SONG], [VOICE], [STYLE], [+/-], [BANK], [STORE (M1-M4)], [ONE TOUCH SETTING], [DUAL], [SPLIT], [RECORD], [PLAY / STOP]</p>	
Auto Accompaniment	[START / STOP], [SYNC], [INTRO / ENDING], [FILL A], [FILL B]	
Record	[REC], [PLAY / STOP]	
Memory	4 banks, each with 4 memory locations	
MIDI	Receive / send	
Connections	Voltage supply AC 230 V ~, 2 x headphones (1/4" phone jack), AUX OUT (L / R), USB, MIDI IN, MIDI OUT, three pedals (Soft, Sostenuto and Sustain)	
Speaker	8 Ω, 2 x 25 W	
Dimensions (W x H x D)	1358 mm x 894 mm x 486 mm	
Weight	45.3 kg	
Housing colour	Black	Item number 352287
	White	Item number 352384

15 Protecting the environment

Disposal of the packaging material



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

Disposal of your old device



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE). Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.



