


- ① Input plug (to cell phone)
- ② Output (to amp)
- ③ Input (from instrument)
- ④ Headphone output



- ✓ 1/4" output jack
- ✓ 1/8" headphones jack
- ✓ 1/4" input jack
- ✓ 185 × 32 × 15 mm (L × W × H)
- ✓ Weight 20 g

# Jackamp Mobile

## Instrument to iPhone Adaptor

### FEATURES

The 1/4" input jack is designed to be connected to a guitar, bass, and it is also applicable for keyboards, microphones, mixers line outputs etc. The 1/4" output jack can be connected to an amplifier or the like.

The 1/8" mm input plug connects to your iPhone. Compatible apps to be used with iPhone/iPad are: Effects, tuners, metronomes, tone generators, recorders, amp simulation etc.

### OPERATION

Jackamp Mobile is the easiest way to send the signal of your instrument into an iPhone, iPod touch or iPad. Just plug the Jackamp Mobile into the device's headphone jack and your instrument into the Jackamp Mobile. Then connect the output of the Jackamp Mobile to an amplifier or another device that offers a line level input, like a mixer etc.

If you listen to the sound using headphones, the output jack will automatically be muted.

Jackamp Mobile can be used with the following devices: iPhone 4 / iPhone 3GS / iPhone 3G / iPod touch 4 / iPod touch 3 / iPod touch 2 / iPad / iPad 2. (iPhone/iPad/iPod touch are registered trademarks of Apple Inc.)

This device is meant to be used as an adaptor to transfer an instrument signal to an iPhone or iPad within the specifications given here. Use the device only as described here. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper usage.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this de-

vice only if they are supervised or instructed by a person who is responsible for their safety.

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke! Never let children unattended use electrical devices.

With headphones connected, the device can produce volume levels that may cause temporary or

permanent hearing impairment. Do not operate the device permanently at a high volume level. Decrease the volume level immediately if you experience ringing in your ears or hearing impairment.



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose of your old device with your normal household waste. Dispose of this product through an approved waste disposal firm or through your local waste facility. Comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

Thomann GmbH  
Hans-Thomann-Str. 1 • 96138 Burgebrach  
Germany • www.thomann.de

*Harley Benton*